

## SHROUDED CAPR OUTER LAYER DOFFING AIRWAY TEAM PPE

### SLOW DOWN, SLOW IS SAFE!

1. IDENTIFY SAFETY OFFICER/BUDDY & DOFFIE
2. DOFFIE **HAND HYGIENE/GEL**
3. DOFFIE UNTIES HOOD BODY TIES, PULLS THEM FORWARD UNTIL FREE, DISPOSE
4. DOFFIE UNTIES HOOD NECK TIES, PULLS THEM FORWARD UNTIL FREE, DISPOSE
5. SAFETY OFFICER and doffie REMOVE **OUTER GLOVES**
6. SAFETY OFFICER and doffie **HAND HYGIENE/GEL** on **INNER GLOVES**
7. SAFETY OFFICER NEW **OUTER GLOVES** on top of **INNER GLOVES**
8. SAFETY OFFICER PLACES 1 CHUX PAD ON CHAIR
9. DOFFIE STANDS STILL NO MOVING.
10. SAFETY OFFICER/BUDDY STEPS BEHIND
11. FILTER CAP REMOVAL- UNTUCK WHITE FILTER COVER CAP, ROLLING FROM BACK TO FRONT, DISPOSE
12. SHROUD REMOVAL – GRASP OUTER SHROUD AT BACK, ROLL UP TO OCCIPUT. GRASP AND LIFT INNER SHROUD AT BACK, ROLL UP TO OCCIPUT, BOTH INNER AND OUTER SHROUDS ROLLED UP TOGETHER
13. DOFFIE GRASPS the shroud AND ROLLS FORWARD, ONCE AT TEMPLES, SLOWLY LIFTS UP AND AWAY. SAFETY

- OFFICER may hold sides of helmet cage in place if needed. DISPOSE shroud!
14. DOFFIE STANDS WITH ARMS STRAIGHT AT SIDES AND LIFTS ARMS FORWARD FROM SIDES TO 15 DEGREES, NO MOVING.
  15. SAFETY OFFICER/BUDDY UNFASTENS NECK VELCRO of DOFFIE'S SURGICAL GOWN, AND UNTIES TIES.
  16. SAFETY OFFICER/BUDDY ROLLS GOWN DOWN TO WRISTS.
  17. SAFETY OFFICER/BUDDY PULLS OFF GOWN. TRASHES GOWN.
  18. DOFFIE **HAND HYGIENE/GEL** on **INNER GLOVES**
  19. DOFFIE NEW **OUTER GLOVES** on top of **INNER GLOVES**
  20. SIT TO REMOVE BOOTIES. UNTIE BOOTIES. FOLD DOWN THE TOP AND PULL OFF SO BOOTIES ARE INSIDE OUT. THROW IN REGULAR **TRASH**
  21. REVERSE ROLES!

**\*SKIP TO INNER LAYER DOFFING ONCE BOTH PARTIES HAVE DOFFED**

WHEN BOTH PARTIES HAVE DOFFED HOOD or HELMET/SHROUD, GOWN, SURGICAL GLOVES, and BOOTIES, you are **SAFE TO LEAVE!**

CONTACT CARLOS OR JODY FOR CHANGES