

N95 INNER LAYER DOFFING AIRWAY TEAM PPE

SLOW DOWN, SLOW IS SAFE!

1. IDENTIFY SAFETY OFFICER/BUDDY
2. **HAND HYGIENE/GEL ON GLOVED HANDS**
3. 1 CHUX ON RIGHT SIDE OF TABLE (FOR "DIRTY" **HELMET**)
4. 1 CHUX PAD ON CHAIR
5. REMOVE **YELLOW GOWN** BY PULLING IT AWAY FROM YOUR WAIST, ROLLING IT INSIDE OUT. THROW IN REGULAR **TRASH**
6. **REMOVE INNER STERILE GLOVES**
7. **HAND HYGIENE/GEL**
8. **NEW GLOVES**
9. OPEN PLASTIC BAG. ROLL IT OPEN. PLACE ONTO LEFT SIDE OF THE TABLE NEAR CHUX.
10. LOOSEN **HELMET** KNOB WHILE HOLDING THE HELMET. LIFT THE HELMET OFF HEAD
11. PLACE **HELMET** ON THE TABLE CHUX
12. REMOVE BATTERY CLIP FROM WAISTBAND AND PUT BATTERY PACK AND CABLE ON THE CHUX ON THE TABLE.
13. DISCONNECT BATTERY FROM THE CLIP -ORTHO HOOD WILL TURN OFF.

14. REMOVE BOUFFANT CAP/BEARD COVER -THROW IN REGULAR TRASH.
15. HAND HYGIENE/GEL
16. REMOVE GOGGLES AND PLACE ON THE CHUX ON THE TABLE.
17. AVOID TOUCHING THE FRONT OF N-95 - GRASP BOTTOM ELASTIC TIE, PULL FORWARD AND OVER YOUR FACE, LET GO. GRASP TOP ELASTIC TIE, PULL FORWARD AND OVER YOUR FACE. THROW IN REGULAR TRASH.
18. REMOVE GLOVES
19. HAND HYGIENE/GEL
20. NEW GLOVES
21. REMOVE FABRIC TABS FROM INSIDE OF ORTHO HELMET - THROW IN REGULAR TRASH.
22. OPEN PDI AF3 (GRAY TOP) CONTAINER- TAKE WIPE, LIFT ORTHO HELMET – WIPE INSIDE OF ORTHO HELMET, THEN OUTSIDE OF HELMET, AND THEN CORD AND BATTERY PACK. AVOID TOUCHING THE CLEAN HELMET/CORD TO DIRTY CHUX DURING CLEANING.
23. PUT CLEAN ORTHO HELMET AND CORD INSIDE PLASTIC BAG TO AIR DRY.
24. THROW AWAY USED AF3 WIPE.
25. OPEN PDI AF3 (GRAY TOP) CONTAINER- TAKE WIPE, CLEAN WIPE BATTERY IF STILL OUT AND PLACE INSIDE OPEN

PLASTIC BAG TO DRY. WIPE GOGGLES. PLACE GOGGLES
INSIDE OPEN PLASTIC BAG TO AIR DRY

26. THROW AWAY USED WIPE & BOTH CHUX IN
REGULAR **TRASH**.

27. **REMOVE GLOVES**

28. **HAND HYGIENE/GEL**

29. **NEW GLOVES**

30. GRAB BAG WITH GOGGLES AND ORTHO HELMET. YOU
ARE **NOW SAFE TO EXIT**

CONTACT CARLOS OR JODY FOR CHANGES