

## N95 OUTER LAYER DOFFING AIRWAY TEAM PPE

### SLOW DOWN, SLOW IS SAFE!

1. IDENTIFY SAFETY OFFICER & DOFFIE
2. SAFETY OFFICER REMOVE your own **OUTER GLOVES**
3. SAFETY OFFICER **HAND HYGIENE/GEL** on **INNER GLOVES**
4. SAFETY OFFICER NEW **OUTER GLOVES** on top of **INNER GLOVES**
5. SAFETY OFFICER PLACES 1 CHUX PAD ON CHAIR
6. DOFFIE STANDS WITH ARMS STRAIGHT AT SIDES AND LIFTS ARMS FORWARD FROM SIDES TO 15 DEGREES. NO MOVING.
7. SAFETY OFFICER STEPS BEHIND AND UNFASTENS NECK VELCRO, AND UNTIES TIES.
8. SAFETY OFFICER STEPS IN FRONT AND ROLLS GOWN DOWN TO WRISTS.
9. SAFETY OFFICER PULLS OFF GOWN. TRASHES GOWN.
10. SAFETY OFFICER/BUDDY PULLS OFF DOFFIE'S **OUTER GLOVES** IF NOT OFF ALREADY. **TRASHES**.
11. SAFETY OFFICER/BUDDY SAYS "Squat down slightly, do not move." DOFFIE COMPLIES.
12. SAFETY OFFICER/BUDDY PULLS BACK OF HOOD OVER TOP OF HEAD, GRASPS SIDES THEN LIFTS MASK OFF OF HOOK, AND PULLS AWAY FROM DOFFIE. **TRASHES** HOOD.

- 13. DOFFIE HAND HYGIENE/GEL on INNER GLOVES**
- 14. DOFFIE NEW OUTER GLOVES on top of INNER GLOVES**
- 15. SIT TO REMOVE BOOTIES. UNTIE BOOTIES. FOLD DOWN THE TOP AND PULL OFF SO BOOTIES ARE INSIDE OUT. THROW IN REGULAR TRASH**
- 16. REVERSE ROLES!**

**\*SKIP TO INNER LAYER DOFFING ONCE BOTH PARTIES HAVE DOFFED**

**WHEN BOTH PARTIES HAVE DOFFED ORTHO HOOD, GOWN, AND SURGICAL GLOVES, you are SAFE TO LEAVE!**