

N95 AIRWAY TEAM DONNING ENHANCED PPE

SLOW DOWN, SLOW IS SAFE!

DONNING AREA INSTRUCTIONS WITH N95, GOGGLES, and ORTHO HOOD

- 1. IDENTIFY SAFETY OFFICER/BUDDY**
- 2. REMOVE ALL PERSONAL ITEMS. NOTHING COMES OUT THAT GOES IN!**
- 3. GET ENHANCED PPE AND AIRWAY BOXES, 2ND SCRUB PAIR (1 size up), BOUFFANT/BEARD COVER, AND YELLOW GOWN, THEN ENTER ANTECHAMBER AND PLACE ON THE TABLE**
- 4. HAND HYGIENE/GEL**
- 5. PUT VA PROVIDED SCRUBS ON TOP OF WORN CLOTHING (optional).**
- 6. HAND HYGIENE/GEL**
- 7. N95 – fix flexible band to nose, snug to face/chin, secure bands 1 at a time, fit check.**
- 8. Put on GOGGLES.**
- 9. BOUFFANT CAP/BEARD COVER.**
- 10. SIT DOWN AND PUT ON ORTHO BOOTIES.**
- 11. HAND HYGIENE/GEL**
- 12. STERILE GLOVES 1ST SET**
- 13. YELLOW GOWN * do not tie yet*.**

14. INSERT **BATTERY INTO ORTHO HELMET**
BATTERY HOLSTER- will turn on.
15. **ORTHO HELMET** ON HEAD, MOVING BATTERY CORD TO YOUR BACK, CLIP BATTERY HOLSTER INTO WAISTBAND OR PLACE IN BACK POCKET
16. ADJUST **HELMET FIT** by dialing knob until it is snug
17. CHECK **HELMET FIT** by leaning forward then moving head side to side
18. TIE **YELLOW GOWN**
19. **ORTHO HOOD ON** – hook plastic face shield notch onto plastic ridge in front, secure magnets on either side in front and unfold over helmet
20. **SURGICAL GOWN ON** – secure neck Velcro, tie back and sides
21. **2ND PAIR OF STERILE GLOVES ON. FIT OVER SURGICAL GOWN SLEEVES.**
22. DOUBLE CHECK HEAD TO TOE COVERAGE.
23. **BRING AIRWAY SUPPLIES, GLIDESCOPE, WALKIE TALKIES, VENTILATOR AND DRUG BAG INTO HOT ZONE**

CONTACT CARLOS OR JODY FOR CHANGES