





AIRWAY TEAM DONNING
3m VERSAFLOW TR300 HEADGEAR
SLOW DOWN, SLOW IS SAFE!

	<u>Optional</u>	<u>Recommended</u>
IDENTIFY SAFETY OFFICER/BUDDY		
REMOVE ALL PERSONAL ITEMS. NOTHING COMES OUT THAT GOES IN! GET ENHANCED PPE AND AIRWAY BOXES	<ul style="list-style-type: none">• Get 2nd scrub pair (1 size up) +/- yellow gown• Bouffant cap/beard cover• N95 in inner scrub pocket for use after doffing	
HAND HYGIENE/GEL	<ul style="list-style-type: none">• Don VA scrubs on top of worn clothing• Bouffant cap/beard cover• Mask (if doffing alone)	<ul style="list-style-type: none">• Mask - if doffing with partner
SIT DOWN AND PUT ON ORTHO BOOTIES		
HAND HYGIENE/GEL		
STERILE GLOVES 1ST SET	<ul style="list-style-type: none">• Tie yellow gown	

<p>CHECK BATTERY CHARGE</p>		
<p>ATTACH BATTERY INTO 3m MOTOR BLOWER UNIT HOLSTER & TURN ON.</p>		
<p>AIRFLOW CHECK (WITH AIRFLOW INDICATOR) AND LOW FLOW CHECK (OCCLUDE with airflow on until red light & alarm beeps)</p>	<p>Airflow indicator: E or D = good</p> 	<p>Low flow check: block flow until alarm beeps</p> 
<p>ATTACH BREATHING TUBE TO TR300</p>		
<p>PUT ON TR300 BELT</p>		

ATTACH BREATHING TUBE TO 3M HEADGEAR HOOD		
DON 3M HEADGEAR	<ul style="list-style-type: none">• ADJUST SPEED OF AIRFLOW BY PRESSING BUTTON (once = low flow, twice = high flow, three times = off)	
SURGICAL GOWN ON – PLACE SHROUD OF 3M HOOD UNDER GOWN AND secure neck Velcro over the PAPR hose, tie back and sides.		
2ND PAIR OF STERILE GLOVES ON. FIT OVER SURGICAL GOWN SLEEVES.		
DOUBLE CHECK 360/HEAD TO TOE COVERAGE		

ENTER HOT ZONE/ANTECHAMBER

BRING AIRWAY SUPPLIES, GLIDESCOPE, WALKIE TALKIES, VENTILATOR AND DRUG BAG INTO HOT ZONE.. CONTACT CARLOS OR JODY FOR CHANGES