

## CAPR AIRWAY TEAM DONNING AIRWAY PPE

SLOW DOWN, SLOW IS SAFE!

### DONNING AREA INSTRUCTIONS WITH CAPR & ORTHO HOOD

1. IDENTIFY SAFETY OFFICER/BUDDY
2. REMOVE ALL PERSONAL ITEMS. NOTHING COMES OUT THAT GOES IN!
3. GET ENHANCED PPE AND AIRWAY BOXES, 2<sup>ND</sup> SCRUB PAIR (1 size up), BOUFFANT/BEARD COVER, AND YELLOW GOWN, THEN ENTER ANTECHAMBER AND PLACE ON THE TABLE
4. HAND HYGIENE/GEL
5. PUT ON VA PROVIDED SCRUBS ON TOP OF WORN CLOTHING (optional).
6. HAND HYGIENE/GEL
7. Optional: put on surgical mask or N95 if desired
8. BOUFFANT CAP/BEARD COVER.
9. SIT DOWN AND PUT ON ORTHO BOOTIES.
10. HAND HYGIENE/GEL
11. STERILE GLOVES 1<sup>ST</sup> SET
12. YELLOW GOWN\* do not tie yet\*.
13. INSERT BATTERY CORD INTO CAPR HELMET BATTERY - will turn on. Check battery level and fan speed.
14. ATTACH CAPR FACE SHIELD TO CAPR HELMET

15. CAPR HELMET ON HEAD, MOVING BATTERY CORD TO YOUR BACK, CLIP BATTERY HOLSTER INTO WAISTBAND OR PLACE IN BACK POCKET
16. ADJUST HELMET FIT by dialing knob until it is snug
17. CHECK HELMET FIT by leaning forward then moving head side to side
18. TIE YELLOW GOWN
19. ORTHO HOOD ON – hold face shield in front of face and unfold hood over helmet. Consider cutting slit in back of hood if concerned about low air circulation during procedure. The hood over CAPR is for head/neck coverage, not virus filtration.
20. SURGICAL GOWN ON – secure neck Velcro, tie back and sides
21. 2<sup>ND</sup> PAIR OF STERILE GLOVES ON. FIT OVER SURGICAL GOWN SLEEVES.
22. DOUBLE CHECK HEAD TO TOE COVERAGE.
23. BRING AIRWAY SUPPLIES, GLIDESCOPE, WALKIE TALKIES, VENTILATOR AND DRUG BAG INTO HOT ZONE

CONTACT CARLOS OR JODY FOR CHANGES