

## CAPR OUTER LAYER DOFFING AIRWAY TEAM PPE

### SLOW DOWN, SLOW IS SAFE!

1. IDENTIFY SAFETY OFFICER & DOFFIE
2. SAFETY OFFICER REMOVE OUTER GLOVES
3. SAFETY OFFICER HAND HYGIENE/GEL on INNER GLOVES
4. SAFETY OFFICER NEW OUTER GLOVES on top of INNER GLOVES
5. SAFETY OFFICER PLACES 1 CHUX PAD ON CHAIR
6. DOFFIE STANDS WITH ARMS STRAIGHT AT SIDES AND LIFTS ARMS FORWARD FROM SIDES TO 15 DEGREES. NO MOVING.
7. SAFETY OFFICER STEPS BEHIND AND UNFASTENS NECK VELCRO, AND UNTIES TIES.
8. SAFETY OFFICER STEPS IN FRONT AND ROLLS GOWN DOWN TO WRISTS.
9. SAFETY OFFICER PULLS OFF GOWN. TRASHES GOWN.
10. SAFETY OFFICER PULLS OFF DOFFIE'S OUTER GLOVES IF NOT OFF ALREADY. TRASHES.
11. SAFETY OFFICER SAYS "Squat down slightly, do not move." DOFFIE COMPLIES.
12. SAFETY OFFICER PULLS BACK OF HOOD OVER TOP OF HEAD, GRASPS SIDES AND PULLS AWAY FROM DOFFIE. TRASHES HOOD.
13. DOFFIE HAND HYGIENE/GEL on INNER GLOVES

14. DOFFIE NEW OUTER GLOVES on top of INNER GLOVES
15. SIT TO REMOVE BOOTIES. UNTIE BOOTIES. FOLD DOWN THE TOP AND PULL OFF SO BOOTIES ARE INSIDE OUT. THROW IN REGULAR TRASH
16. REVERSE ROLES!

**\*SKIP TO INNER LAYER DOFFING ONCE BOTH PARTIES HAVE DOFFED**

WHEN BOTH PARTIES HAVE DOFFED ORTHO HOOD, GOWN, SURGICAL GLOVES, and BOOTIES you are **SAFE TO LEAVE WITH CAPR HELMET AND FACE SHIELD STILL ON!**